

## Cold Peel DTF Transfer Instructions

\*The tiny speckles you see on the sheets around the print are excess powder. After completing step 7 it will disappear and no longer be visible on the garment/item.\* \*Disregard the shadows you see on the sheets, it will not affect the print or transfer over to the garment\*

1. Set press to 300 degrees.
2. Pre-press garment for 5-10 secs (this helps smooth out fabric and ensure a successful transfer)
3. Place DTF sheet as needed (recommend using a teflon sheet or parchment paper while pressing as a protective layer).
4. Press DTF sheet for 20 secs with heavy pressure. (10-15 secs for finer polyester garments)
5. Before peeling remove garment from heat to cool for about 30secs.
6. Slowly peel DTF print paper off, and place protective layer \*If you have issues peeling, try peeling from a different direction/ edge first. If you still have issues repress for about 5- 10 secs
7. Press garment for an additional 20 secs to cure print.
8. Check to see if DTF print lifts off the garment, if so press for another 5-10 secs. If not, you can take garment off the press